

FW0033
Original Heat
Exchanger
connection



1. Fit the Heat Exchanger onto the Water Heater

FW0033

New Type Heat Exchanger



2. Fit the Heat Exchanger bracket above the brass racord as shown



3. Fit the hot water pipe to the brass racord



4. Tighten the brass racord and 19mm nut, using a pipe wrench and a 19mm spanner